

SIMATIC-Ka

Canon H		Vstupy	
2		I 0.0	RK A
3		I 0.1	RK B
4	6	+24V	
1	40	0V	
	35	I 0.2	10x
	30	I 0.3	SAC
	18	I 0.4	urychlení
	38	I 0.5	W
	25	I 0.6	LU
	24	I 0.7	PU
	31	I 1.0	UAC
	34	I 1.1	POB
	39	I 1.2	ZPS
	37	I 1.3	PPS
	33	I 1.4	rychloposun vzad
	32	I 1.5	rychloposun vpred
	29	I 8.4	3. imp. nulový
	28	I 8.5	2. imp. mer.
	27	I 8.6	1. imp. mer.
	26	I 8.7	meridlo vpredu
	20	I 8.0	Err. hl. A
	21	I 8.1	Err. hl. B
	22	I 8.2	Err. hl. C
		I 8.3	
		Výstupy	
		Q 0.0	
	8	Q 0.1	10x
		Q 0.2	KM jede
		Q 0.3	KM stojí
		Q 0.4	
	7	Q 0.5	meridlo vpred
	9	Q 0.6	KAC
	12	Q 0.7	X>WSP
	10	Q1.0	Z stop
	11	Q1.1	X<WSP

Simatic 18_3
RELÉOVÝ

ZF_Witten

Canon X			
2		I 4.0	Enkodér KM A
3		I 4.1	Enkodér KM B
9		L+	+24V
1		M	0V

SD11	Canon S				
Freq	9	2kO	SB	Q 4.0	KM Pulse
Dir	8	2kO	SB	Q 4.1	KM Direction
Icontl.	6	2kO		Q 0.3	KM stojí
+24V	5			L+	+24V

tisk 14.06.18 22:41